

## **CODE FREE MODIFICATION FOR ZENEC ZE-100DVD HEADUNIT**

- 1) Press the „EJECT“ button and take out a loaded disc. Now you can only see the background picture.
- 2) Press the button sequence „**8-4-2-1**“ (numeric buttons on the remote control) and you should now be able to see the factory preset Region Code number of the device, for example 1 or 2.
- 3) Press the "ENTER" button until the Region Code displayed reads "All".
- 4) When the displayed Region Code is "All", press the "PLAY" button and the headunit will store the new Region Code (CODE FREE). After this procedure, the ZE100DVD can play disks from ALL REGIONS.

## **LÄNDER-CODE MODIFIKATION FÜR ZE-100DVD HEADUNIT**

- 1) Drücken Sie die Taste „EJECT“ um eine im Laufwerk geladene Disk auszuwerfen. Sie sehen nun nur ein Hintergrund Bild auf dem Monitor.
- 2) Drücken Sie die Tasten-Sequenz „8-4-2-1“ auf der numerischen Tastatur der Fernbedienung. Das Gerät zeigt nun den eingestellten default Länder-Code an, also z.B. 1 oder 2.
- 3) Drücken Sie wiederholt die Taste „ENTER“ und zwar so lange, bis das Gerät „ALL“ anzeigt.
- 4) Wenn das Gerät „ALL“ anzeigt, drücken Sie die Taste „PLAY“ auf der Fernbedienung, um den CODE FREE Mode zu bestätigen und abzuspeichern. Nach dieser Prozedur spielt das Gerät DVD's von allen Regionen!